



Installation handbook



Manuel d'installation



Manual de instalación



Manuale di installazione



Installationshandbuch

Eccolo

Recommendations

Read this manual carefully before using your sauna for the first time.

We recommend you keep it in a safe place for future reference.

- Install the sauna on a perfectly flat surface.
- The sauna must remain in a dry area. Do not use it near a source of water (bath, damp floor, swimming pool).
- Do not use liquid cleaning products. Disconnect the sauna before cleaning and use a wet rag (see Maintenance section).
- Protect the sauna's electrical cable to avoid it being crushed or pinched.
- Prior to replacing certain components, ensure that they are specified by the manufacturer or that they have the same features as the original parts. Incorrect replacement can cause a fire, a short circuit or damage to the sauna. We strongly recommend using a qualified technician.
- To avoid the risk of burns or electric shocks, do not use any metal tools.
- Do not put animals in the sauna.
- Do not leave the sauna switched on without supervision.
- Do not leave the sauna switched on for more than 3 hours at a time to avoid premature deterioration of the equipment. After 3 hours continuous usage, switch off the sauna for at least one hour.
- We recommend that you do not install a locking system on the sauna door.
- Check compliance of your electrical installation prior to connecting your sauna to the power supply.
- Write down and keep the serial numbers of the sauna as well as the purchase invoice. They may be requested from you during your after-sales service request.

Safety

IMPORTANT:

Please read the safety instructions carefully before installing and using your sauna cabin. They are essential for your safety, so please adhere strictly to them.

EN

Beware of hyperthermia, heat stroke or heat exhaustion which can be caused or aggravated by noncompliance with the safety instructions. Symptoms are fever, a rapid pulse, dizziness, fainting, lethargy and numbness in all or part of the body. The effects are: reduced awareness of the heat, ignorance of imminent risks, loss of consciousness.

The sauna must not be used by:

- Children under 6 years of age.
- People with severe reactions to sunlight.
- Elderly or disabled people.
- People with previous medical conditions such as heart disease, high or low blood pressure, blood circulation problems or diabetes without prior medical advice.
- Pregnant women. Excessive temperature can endanger the fetus.
- Persons suffering from dehydration, open sores, eye disorders, burns or sunstroke.

Children between 6 and 16 years of age may use the sauna provided that they are continuously supervised by a responsible adult and that the temperature does not exceed 60°C (140°F).

In the event of problems involving health, medication or injury to muscles or ligaments, do not use the sauna without previously consulting a doctor and obtaining approval.

If surgical implants are worn, do not use the sauna without previously consulting a doctor and obtaining his approval.

Do not use the sauna after strenuous activity.

Wait 30 minutes for your body to cool down.

Do not spend more than 40 minutes in the sauna at any one time.

Do not consume alcohol or drugs before or during the session.

Do not sleep in the sauna when it is in operation.

To avoid the risk of overheating, connect your sauna to a sufficiently powerful electrical outlet and do not connect other electrical equipment to the same wall socket.

To avoid any risk of electrocution or damage to the sauna, do not use it:

- During thunderstorms.
- If the electrical cable is damaged, it must be replaced by a qualified person.
- If the electrical cable overheats, it must be checked by a qualified person.
- If you have to change a bulb, wait until the sauna is switched off and cooled down.

Dry your hands before connecting or disconnecting the electricity.

Never work with wet hands or feet.

Do not switch the electricity or the heating system rapidly on or off as this could damage the electrical system.

Do not try to repair the sauna by yourself without the agreement of the sauna's distributor or manufacturer.

Unauthorized attempts to repair it will invalidate the manufacturer's warranty.

Do not use any type of detergent inside the sauna.

Do not pile up or store objects inside or on top of the sauna.


Do not place flammable materials or chemical agents near the sauna.


Description sauna

Technical data

Model	HL-EC04-MX
Cabin Material	Cèdre rouge et abachi

Parts List



	Size	QTY
	Ø 4 x 35	14
	Ø 4 x 45	10
	Ø 6 x 50	15

N°	Name	QTY
1	Front panel	1
2	Side panel 1	1
3	Side panel 2	1
4	Floor panel	1
5	Back panel	1
6	Top panel	1
7	Bench support panel 1	1
8	Bench support panel 2	1
9	Bench surface panel 1	1
10	Bench surface panel 2	1
11	Bench surface panel 3	1
12	Bench surface panel 4	1
13	Cradle of the stove	1
14	Decorative bar	4
15	Door handle	2
16	MDF cover	1

Installation

Read the assembly instructions carefully before starting.

Choice of location

Holl's saunas are designed solely for interior installation.

Select a space:

- Inside, in a dry area, on a flat stable surface that can support the weight of your sauna.
- The height must be sufficient for you to reach the ceiling and carry out electrical connections and maintenance.
- Away from any source of water, flames or flammable materials.

Practical advice

- Note that sauna assembly requires 2 or 3 adults.
- Clearly identify each panel before you begin
- During assembly, position your sauna's mains cable so that it is easily accessible.
- Note that there are variations between the models.

IMPORTANT:

Please check the countersink and hole diameter of the drill holes to avoid damaging the wood.
The minimum room height required for installation is 2020 mm.

Tools needed



Screwdriver



Tape measure




Step ladder



Pencil



Cutter



Hammer



Allen wrench




Bubble level

Assemble instructions


Assemble steps

Step 1:



step1



Step2




Step3




Step 2:

Step 3:

step1




Step2




Step3





step1



Step2




Step3




Assemble instructions


Step 4:



Step 5:





Step 6:





Assemble instructions

Step 7:






60*5(4pc)

Step 8 :






Assemble instructions

Step 9:



Step 10:




平头内六角螺丝2PC

EN

Using the sauna

Chromotherapy



Input	DC 12V - 24V
Output	Max 18A
Remote controller battery	3 x AAA battery

- You can choose different changing mode, adjust the speed and brightness, turn ON/OFF by the remote control according to your preference.
- This controller is with power off memory function, next time to used it, will start with the model it save.
- Its built-in 7 kinds of static color, jump, fade, strobe, flow, automatic cycle and others effect.
- This controller is with short circuit protection function. When meet short circuit, its green indicating light will be twinkling in a fixed frequency to indicate this to you. In second time it automatically restore function after short circuit protection.

N°	Mode	Remarks
01	Static red	Brightness is adjustable. Speed is unadjustable.
02	Static green	
03	Static blue	
04	Static yellow	
05	Static purple	
06	Static cyan	
07	Static white	
08	3 colors: jumpy changing	Brightness and speed are adjustable.
09	3 colors: gradual changing	
10	7 colors: jumpy changing	
11	7 colors: gradual changing	
12	Red stroboflash	
13	Green stroboflash	
14	Blue stroboflash	
15	Yellow stroboflash	
16	Purple stroboflash	
17	Cyan stroboflash	
18	White stroboflash	
19	R/B crossfade	Brightness is adjustable. Speed is unadjustable.
20	B/R crossfade	
21	G/B grossfade	
22	Colors right crossfade	Brightness and speed are unadjustable.

IMPORTANT:

- It is not a waterproof product, please keep it away water.
- Well heat dissipation will extend the product life time.
- Do not install it in intense magnetic field or near the high voltage source.
- For safety, be sure that operating current does not overload the wire capability.
- Before power on, make sure the ports are connected properly, wrong connection will damage the products.

Maintenance & servicing

Maintenance

IMPORTANT:

Disconnect the cabin's power supply cable before undertaking any work.

EN

Problems identified	Possible reasons	Solutions
Electric stove does not heat up.	Power supply cable disconnected.	Check power supply cable connection.
	The general power supply is cut.	Check that the switchboard and wall plug are working.
	Stove is overheat protected.	Refer to the electric stove manual.
Sauna light fitting no longer work.	LED cable not fully plug.	Plug the cable.
	LED is defective.	Contact your dealer.
	LED doesn't respond.	Change remote control batteries.

Servicing

1. Disconnect your sauna.
2. Use a vacuum cleaner to remove dust from crevices in the woodwork.
3. Clean the cabin with a damp cotton cloth and use a small amount of soap if necessary. Rinse with a damp cloth.
4. Clean the glass with a window / glass cleaner and a soft cloth.

IMPORTANT:

Do not use benzene, alcohol, chemical agents or strong detergents on the sauna since chemical products can damage the wood. Do not spray water on your sauna.

Warranty

All the components of Holl's saunas are guaranteed for 2 years.

The warranty comes into force on the date of dispatch (corresponding to the date the invoice is issued).

The warranty does not apply in the following cases:

- Malfunction or damage arising from installation, usage or repair that are not in compliance with the safety instructions.
- Malfunction or damage arising from conditions that are unsuitable for the equipment's originally intended purpose.
- Damage arising from negligence, accident or force majeure (thunderstorm or bad weather).
- Malfunction or damage arising from the use of non-authorized accessories.
- Degradation linked to parasites attacking the wood, within a period of more than 3 months after the date of delivery.

The warranty does not cover the costs linked to returning the cabin or part of its components to our workshops of.

Under the warranty, in the event of a breakdown, the items deemed defective by our technicians will be exchanged.

Information and explanations required for their installation will be provided by one of our technicians.

Costs linked to the use of subcontract labour provided by a third party cannot be covered by Holl's.



IMPORTANT

Do not return the product to the store

Contact your local after sales service on

www.holls.fr or POOLSTAR FRANCE

960 Avenue Olivier Perroy - 13790 ROUSSET - FRANCE



www.holls.fr

Technical assistance - Assistance technique
Asistencia técnica - Assistenza tecnica
Technische Unterstützung

+33 (0)4 91 51 01 99



03/2022